

Installation hints



Clean: Clean tool kit with a wire brush before working with aluminium.

Cut: Push back insulation and cut the pipe with a conventional cutting tool.

Connect: Standard flare nuts or mechanical connections can be used for joining aluminium pipes.

Protect: Protect the joint with a heat shrink sleeve to avoid galvanic corrosion!

