

# ARMAFIX ECOLIGHT APPLICATION GUIDE

Select the correct size of Armafix pipe support (at least the insulation thickness of the tube). The stamp on the pipe support indicates the applicable pipe dimension.



1 Install Armafix Ecolight pipe support on the pipe, seal the surfaces using Armaflex adhesive and remove the protective paper strip on the overlapping PVC cover.



2 Close the seam applying firm pressure. Push the pipe support into the open clamp. It must be in the middle of the clamp.



3 Tighten the screws.



4 Before insulating the pipe, glue the edges of the pipe support to the pipe.



5 Wet seal the butt joints using Armaflex adhesive.



6 Install Armaflex insulation on either side of the pipe support. Ensure that the pipe insulation is installed under slight compression.