

Permitted loads

for ArmaFix AF, ArmaFix NH und ArmaFix Ultima

www.armacell.eu



Pipe max. outside-Ø	Max. permitted load [N]	Max. distance between supports [m]
12	53	2
14	70	2
18	78	2
20	94	2,75
22	104	2,75
26	132	3
28	140	3
32	156	3,5
35	197	3,5
40	222	3,75
42	248	3,75
48	339	4,25
54	358	4,25
60	548	4,75
67	600	4,75
70	609	4,75
75	664	5,5
76	890	5,5
89	1.270	6
92	1.286	6
108	1.452	6
114	1.930	6

Pipe max. outside-Ø	Max. permitted load [N]	Max. distance between supports [m]
125	2.111	6
140	2.722	6
160	3.098	6
168	3.217	6
180	4.369	6
219	6.262	6
225	6.430	6
273	8.511	6
280	8.730	6
323	10.098	4,5
355	11.087	4,2
368	11.473	4,2
406	12.670	4,2
457	14.248	3,7
508	15.838	3,4
610	19.018	2,9
660	20.577	2,6
700	21.824	2,9
711	22.167	2,6
813	25.347	2,6
914	28.496	2,4
1016	31.676	2,2

All data and technical information are based on results achieved under typical application conditions. It is the customer's responsibility to verify if the product is suitable for the intended application. The responsibility for professional and correct installation and compliance with relevant building regulations lies with the customer.